

DISPLAY **A**

Watch hands

60 seconds counter
30 minutes counter
1/10 second counter
Hour hand
Date-indicator
Minute hand
Sekund hand
Setting crown (position I, II, III)
Pushbutton A
Pushbutton B

SETTING THE COUNTERS TO ZERO **B**

Setting crown in position II

1 Setting crown
2 Zero-setting the selected hand.

Selecting the counter for zero-reset. (The selected hand moves).

SETTINGS **C**

Setting crown 3 positions

Normal running of watch
Rapid correction of the date
Correction time position: stop second and correction of the date at every passing to midnight

Note
Setting crown in position III: **STOP-SECOND**

TIMING MODE **D**

Simple timing function

1 START
2 STOP
Read time
- 5 minutes
- 57 seconds
- 7/10 second
3 Reset to zero
Setting crown in position I

1 to 3 order of functions

WARNING
Before starting the time, put back the chronograph hands to their original position. If necessary, see paragraph **SETTING THE TIMERS TO ZERO**



WWW.COVERWATCHES.COM

ETA G10.212 AB PWD

633 497 - 31.07.2015 / ETA / 00

TIMING MODE **E**

ADD function

1 START
2 Setting crown in position I
3 STOP Read
4 RESTART
5 STOP Read
6 STOP Read
X Reset to zero after a STOP

1 to X order of functions

TIMING MODE **F**

SPLIT-TIME or INTERMEDIATE TIMES function

1 START
2 Setting crown in position I
3 SPLIT 1
Read time 1
- 5 minutes
- 4 seconds
- 6/10 second
4 RESTART (catching-up)
5 SPLIT 2
Read time 2
- 15 minutes
- 36 seconds
- 8/10 second
6 RESTART (catching-up)
7 STOP Read LAST TIME
- 25 minutes
- 18 seconds
- 4/10 second
Reset to zero

1 to 7 order of functions