

**DISPLAY** **A**

Watch hands

60 seconds counter  
30 minutes counter  
1/10 second counter  
Hour hand  
Minute hand  
Date indicator  
Second hand  
Pushbutton A  
Pushbutton B  
Setting crown (position I, II, III)

**SETTING THE COUNTERS TO ZERO** **B**

Setting crown in position II

1 Setting crown  
2 Zero-setting the selected hand.

Selecting the counter for zero-reset. (The selected hand moves).

**SETTINGS** **C**

Crown 3 positions

Normal running of watch  
Rapide correction of the date  
Correcting time position: stop second and correction of the date at every passing to midnight

**Note**  
Setting crown in position III : STOP-SECOND

**TIMING MODE** **D**

Simple timing function

1 START  
2 STOP  
3 Reset to zero

Read time  
- 5 minutes  
- 57 seconds  
- 7/10 sec

Reset to zero  
Setting crown in position I

1 to 3 order of functions

**WARNING**  
Before starting the time, put back the chronograph hands to their original position.  
If necessary, see paragraph SETTING THE TIMERS TO ZERO.

**TIMING MODE** **E**

ADD function

1 START  
2 Setting crown in position I  
3 STOP Read  
4 RESTART  
5 STOP Read  
6 RESTART  
7 STOP Read

X Reset to zero

1 to X order of functions

**TIMING MODE** **F**

SPLIT-TIME or INTERMEDIATE TIMES function

1 START  
2 Setting crown in position I  
3 RESTART (catching-up)  
4 SPLIT 2  
5 RESTART (catching-up)  
6 STOP Read  
7 Reset to zero

Read time 1  
- 5 minutes  
- 4 seconds  
- 6/10 sec

Read time 2  
- 15 minutes  
- 36 seconds  
- 8/10 sec

LAST TIME  
- 25 minutes  
- 18 seconds  
- 4/10 sec

1 to Z order of functions



WWW.COVERWATCHES.COM

ETA G15.212 AB PWD