


DISPLAY**A**

Watch hands

**SETTINGS****B**

Normal running of watch



Normal running of watch

SETTINGS**C**

Quick corrections

Quick correction of the date



Quick correction of the moon phase

SETTINGS**D**

Settings

Position for setting the time
(The calendar skips once every 24 hours)
(The moon phase skips forward once every 24 hours)



Position for setting the time
(stop second)

Note :Crown in position III : **STOP SECOND**

GB USA



COVER[®]
SWITZERLAND

WWW.COVERWATCHES.COM

ETA F05.841
Phase de lune

ETA SA Manufacture Horlogère Suisse
depuis 1793